

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children and pets are present, take basic safety precautions, including the following:

- KEEP OUT OF REACH OF CHILDREN!
- READ ALL INSTRUCTIONS BEFORE USING
- KEEP AWAY FROM WATER

DANGER — As with most electrical appliances, parts are electrically live even when the switch is off. To reduce the risk of death by electric shock:

- 1. Always unplug appliance immediately after using.
- 2. Do not use while bathing or in the shower.
- 3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- 4. Do not place in, or drop into, water or any other liquid.
- 5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

- 1. This appliance should never be left unattended when plugged in.

- 2. Do not pull, twist, or wrap line cord around appliance.
- 3. This appliance should not be used by, on, or near children or individuals with certain disabilities.
- 4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer. Do not use an extension cord to operate appliance.
- 5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.
- 6. Keep the cord away from heated surfaces.
- 7. Never use while sleeping.
- 8. Never drop or insert any object into any opening.
- 9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- 10. Do not use an extension cord with this appliance.
- 11. This appliance is hot when in use. Do not let heated surfaces touch eyes or skin.
- 12. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair and the like.

- 13. Do not place the appliance on any surface while it is operating.
- 14. Do not touch hot surfaces of the appliance; use handles or knobs.
- 15. Do not use this appliance near bathtubs, showers, toilets or any other recipient containing water.
- 16. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 17. Before plugging in, read the information about dual voltage contained in the “DUAL VOLTAGE” section of this manual.

SAVE THESE INSTRUCTIONS

SAFETY INSTRUCTIONS


- 1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 2. Children should be supervised to ensure that they do not play with the appliance.
- 3. Burn Hazard. Keep appliance out of reach from young children, particularly during use and cool down.

DUAL VOLTAGE

This straightening iron has dual voltage. It will automatically adjust to the proper voltage. Use an adapter plug (not included) with correct configuration, prior to use in outlet.

- 1. Plug the straightening iron into a standard electrical outlet (120-240V~). It is not necessary to touch the iron with your hand to judge readiness.
- 2. Use the +/- temperature controls to select the setting for your hair type. You can use the chart outlined as a reference. The iron will heat up very quickly.

TEMPERATURE SETTINGS



OPERATING INSTRUCTIONS

This appliance is intended for professional use. Use on Alternating Current (50-60Hz) only. Standard appliances are designed to operate at 120-240V~.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

- 3. Section dry hair evenly, and comb each section. Position the iron on the hair as far up as you want hair to be straightened, being careful not to let the iron touch the scalp. Close the iron with the hair between the two plates and gently pull the iron down to the end of the section of hair you are straightening. Repeat this process several times, if necessary. Let the hair cool before combing.

STYLING TIPS USING STRAIGHTENER

For short, spiky looks use gel or spray and hold the sections up and away from the head while you straighten.

For smoothing and taming curly hair, or creating a stylish, smooth bob, use the straightener just on the ends, leaving the hair wavy at the roots for lift and body. For this type of effect, keep the straightener moving while following the shape of your hairstyle.

For looser waves, close and lock the iron and use it as a wand. Wrap hair around the front housing and hold for a few seconds to create a looser, free-flowing wave.

For tighter curls, turn iron 180° (top-down) and start close to the root or wherever you want the curl to start. Lightly hold hair between plates and turn the iron as you move it down the strand. The slower the turn, the tighter the curl. Adjust the angle to create different types of curls.

For zig-zag styles, open the iron, wrap hair around plates/ housing in a figure 8, hold for a few seconds and release.

For flip and bend waves, turn the iron as you reach the end of hair strand – inward or outward – to create a flip, bend or more body.

For ideal results, use finishing sprays after styling, if desired. Unprecedented performance, design, and versatility – the OPTIMA9000™ by BaBylissPRO™.

NANO TITANIUM

Your Nano Titanium straightening iron has many benefits. Titanium is an exceptional conductor of heat and is stable in ultrahigh temperatures. The titanium plating technology helps provide the ultimate heat performance for beautiful, healthy-looking hair. Titanium's light weight and smooth surface helps reduce time and fatigue and is exceptionally resistant to chemical corrosion. This Nano Titanium iron will give your hair a smooth, silky shine while eliminating frizz.

GET TO KNOW YOUR PROFESSIONAL STRAIGHTENER

Model BNT9000TXLUX - 1¼"

NEW FLOATING PLATE SYSTEM

Ideal for controlling hair tension.



Unlock for floating plates that provide greater smoothness. Ideal for straight styling.

Lock if you want stronger pressure specifically if you are doing any treatment like Keratin.

NOTICE

THIS PRODUCT IS EQUIPPED WITH AN INSTANT HEAT CIRCUITRY. DO NOT LEAVE PRODUCT ON OR PLUGGED IN WHILE NOT IN USE. UNIT WILL BURN OUT IF POWER IS KEPT ON FOR AN EXTENDED PERIOD OF TIME. WARRANTY WILL BE VOIDED. TURN UNIT OFF AND UNPLUG WHEN NOT IN USE.

USER MAINTENANCE

Your styler is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool. Twist off cover and wipe curl chamber and cover with a soft damp cloth. Replace cover back on unit after dried. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

WARNING:

IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination, but did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES.

ESSENTIAL TIPS FOR USAGE

To properly care for your hair and effectively utilize your BaBylissPRO Nano TitaniumXL™ straightener, adhere to these crucial tips:

Utilize the appropriate temperature setting based on your hair type and condition. Refer to the temperature chart provided and opt for the most suitable option. For bleached or highly damaged hair, it is advisable to use a lower temperature setting.

Always apply a thermal protector to your hair before using the straightener. This protective layer helps safeguard your hair strands from heat damage.

Avoid subjecting your hair to excessive heat exposure. Refrain from keeping the straightener stationary on any hair section for prolonged periods. The number of passes required over each section varies depending on factors such as hair type, temperature setting, ongoing treatments like keratin applications, and more. Ensure to glide the straightener over each hair segment only as needed. Refer to the temperature chart for guidance.

Temperature	Hair Type	For Straightening	For Keratin
		Plate Configuration: Floating	Plate Configuration: Fixed
		*Number of Passes	*Number of Passes
300°F/150°C	Fragile	3	10
330°F/165°C	Very Thin	3	10
360°F/180°C	Thin	3-5	10-15
390°F/200°C	Normal	3-5	10-15
420°F/215°C	Curly	3-5	10-15
450°F/230°C	Thick	3-5	10-15
485°F/250°C	Very Coarse Thick	3-5	10-15

*Please note that while these guidelines were based on tests conducted by professional stylists in a salon setting, individual results may vary depending on hair condition, thickness, user perception, and desired styling preferences.

©2025 BaBylissPRO

IB-25/419

Para su seguridad y para disfrutar plenamente de su aparato, siempre lea las instrucciones adjuntas cuidadosamente antes de usarlo.

MEDIDAS DE SEGURIDAD IMPORTANTES

Al usar aparatos eléctricos, especialmente en presencia de niños, siempre debe tomar precauciones básicas de seguridad, incluso las siguientes:

¡MANTÉNGALO FUERA DEL ALCANCE DE LOS NIÑOS!
LEA TODAS LAS INSTRUCCIONES ANTES DE USARLO
MANTÉNGALO ALEJADO DEL AGUA

PELIGRO — Como es el caso de la mayoría de los aparatos eléctricos, los componentes eléctricos de este aparato permanecen bajo tensión cuando está conectado, incluso si está apagado. Para reducir el riesgo de descarga eléctrica:

1. **Siempre desconéctelo inmediatamente después de usarlo.**
2. No lo use mientras se esté bañando o en la regadera.
3. No deje ó guarde el aparato donde éste pueda caer ó ser jalado a la tina ó al lavabo.
4. No lo coloque o deje que le caiga agua u otro líquido.
5. Si un aparato ha caído en el agua, desconéctelo inmediatamente. **No trate de sacarlo del agua.**

ADVERTENCIA — Para reducir el riesgo de quemaduras, electrocución, fuego ó daño a personas:

1. **Nunca deje el aparato desatendido mientras está conectado.**
2. **No jale, retuerza, ni enrolle el cable alrededor del aparato.**
3. Este aparato cuando no debería ser utilizado por, sobre o cerca de niños o personas con alguna discapacidad.
4. Use este aparato únicamente con el propósito para el cual fue diseñado y tal como se describe en este manual. Sólo use accesorios recomendados por el fabricante.
5. **Nunca utilice el aparato si el cable o la clavija están dañados, si no funciona correctamente, si ha caído, si está dañado o si ha caído al agua. Llévelo a un centro de servicio autorizado para que lo examinen y lo reparen.**
6. Mantenga el cable alejado de las superficies calientes.
7. Nunca utilice el aparato mientras usted duerme.
8. Nunca deje caer ni inserte un objeto en ninguna de las aberturas.
9. No lo utilice al aire libre, ni donde se estén usando productos en aerosol (spray) o donde se esté administrando oxígeno.
10. No utilice una extensión eléctrica con este aparato.

GUARDE ESTAS INSTRUCCIONES

PRECAUCIONES

1. Los niños o las personas que carezcan de la experiencia o de los conocimientos necesarios para manipular el aparato, o aquellas cuyas capacidades físicas, sensoriales o mentales estén limitadas, no deben utilizar el aparato sin la supervisión o la dirección de una persona responsable por su seguridad.
2. Asegúrese de que los niños no jueguen con este aparato.
3. Riesgo de quemaduras. Mantenga este aparato fuera del alcance de los niños pequeños, especialmente durante su uso y mientras se enfría.


DOBLE VOLTAJE
Este aparato es doble voltaje. Se adaptará automáticamente al voltaje correcto. Sin embargo, se deberá utilizar un adaptador adecuado (no se incluye) para poder conectar el aparato al tomacorriente.

FUNDAMENTOS DEL ALISADO
1. Conecte el cable a una toma de corriente de 120-240V~. No es necesarios tocar las placas para cerciorarse de que está listo.
2. Escoja el ajuste de temperatura deseado. Utilice la tabla para determinar cual nivel de temperatura escoger, según su tipo de cabello. El aparato calentará muy rápidamente.

INSTRUCCIONES DE OPERACIÓN

Este aparato ha sido diseñado para uso profesional. Utilicelo solamente con corriente alterna (50-60Hz). Los aparatos estándares están diseñados para funcionar con corriente de 120-240V~.

Este aparato tiene una clavija polarizada (un polo es más ancho que otro). Como medida de seguridad, se podrá enchufar de una sola manera en la toma de corriente polarizada. Si no entra por completo, inviértela. Si aún no entra completamente, llame a un electricista calificado. No intente vencer esta función de seguridad.



3. Divida el cabello seco en secciones parejas y peine cada sección. Coloque la plancha cerca del cuero cabelludo, sin permitir que las placas toquen éste. Abra las placas y ponga una sección de cabello entre ellas. Cierre las placas y baje la plancha lentamente hasta las puntas, manteniendo las placas bien cerradas. Alise cada sección varias veces si fuera necesario. Permita que el cabello enfríe antes de peinarlo.

CONSEJOS PARA UN MEJOR ALISADO
Para obtener un efecto de punta con cabello corto, aplique gel o spray al cabello y estire las secciones hacia arriba mientras alisa el cabello.
Para alisar y suavizar el cabello rizado o crear un “bob” terso y moderno, use el aparato en las puntas únicamente, dejando ondas en las raíces para crear cuerpo y movimiento. Mantenga la plancha en movimiento constante y siga la forma del peinado.

Para conseguir ondas sueltas y naturales, cierre y bloquee las placas y use la plancha como rizador. Enrolle el cabello alrededor de la cubierta y espere por unos segundos antes de soltar el cabello.
Para conseguir rizos más apretados, volteee el aparato para que la punta apunte hacia abajo y colóquela cerca de la raíz o donde quiera que empiecen los rizos. Coloque una sección de cabello entre las placas y gire la tenaza sobre sí misma mientras la desliza hacia las puntas. Cuanto más despacio gira

la tenaza, más apretados los rizos. Ajuste el ángulo de la tenaza para crear distintos tipos de rizos.
Para conseguir ondas en forma de zigzag, abra las placas y enrolle el cabello en forma de ocho alrededor de las placas/cubierta. Espere por unos segundos antes de soltar el cabello.
Para doblar las puntas, gire la plancha hacia dentro o fuera al llegar a las mismas. Nota: también puede usar la misma técnica para dar cuerpo. **Para resultados óptimos, utilice un spray de acabado después del peinado si desea.** Rendimiento, diseño y versatilidad sin precedentes — la plancha alisadora/rizadora OPTIMA9000™ de BaBylissPRO™.

NANO TITANIUM
Su plancha alaciadora con placas de Nano Titanium brinda muchas ventajas. El Nano Titanium es un excelente conductor térmico que permanece estable a temperaturas extremas. La tecnología del Nano Titanium utiliza micro-partículas de titanio para lograr un desempeño óptimo y dejar el cabello hermoso y saludable. El Nano Titanium emite calor infrarrojo lejano que penetra profundamente en el tallo del pelo, logrando un peinado más suave para el cabello. El Nano Titanium también emite iones negativos, los cuales logran resultados más rápidos al mismo tiempo que preservan el balance hídrico del cabello. Su plancha alaciadora con placas de Nano Titanium dejará su cabello suave y sedoso al mismo tiempo que eliminará el frizz.

FAMILIARÍCESE CON SU PLANCHALISADORA PROFESIONAL

Modelo BNT9000TXLUX - 1¼"

NUEVO SISTEMA DE PLACA FLOTANTE

Ideal para para controlar la tensión del cabello.



Desbloquee para placas flotantes que proporcionan una mayorsuavidad. Ideal para estilizado lacio.

Bloquee si desea una presión másfuerte específicamente si realizara algún tratamiento como Keratina.

AVISO

ESTE APARATO ESTÁ EQUIPADO CON UN MECANISMO DE CALENTAMIENTO INSTANTÁNEO. NO DEJE EL APARATO ENCENDIDO O CONECTADO CUANDO NO ESTÁ EN USO. EL ELEMENTO CALENTADOR PODRÍA QUEMARSE SI EL APARATO PERMANECIERA ENCENDIDO DURANTE UN PERÍODO PROLONGADO.

ESTO INVALIDARÁ LA GARANTÍA. SIEMPRE APAGUE Y DESCONECTE EL APARATO DESPUÉS DEL USO.

INSTRUCCIONES DE MANTENIMIENTO

Su aparato requiere poco mantenimiento. No necesita lubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que se enfríe y limpie la superficie exterior con un paño humedecido. En caso de mal funcionamiento, desconecte el aparato, permita que se enfríe y regréselo a un centro de servicio autorizado. No trate de reparar este aparato.

PRECAUCIÓN

NUNCA jale, tuerza ni retuerza el cable eléctrico. Nunca lo enrolle con fuerza alrededor del aparato; esto puede dañar la junta flexible que lo conecta al aparato, produciendo su ruptura o un cortocircuito. Revise el cable con frecuencia para asegurarse de que no está dañado. Deje de usar el aparato inmediatamente si el cable está visiblemente dañado o si el aparato deja de funcionar o funciona de manera intermitente.

ALMACENAJE

Cuando no lo utiliza, su aparato es fácil de almacenar. Déjelo enfriar y guárdelo en su caja, en un lugar seco y seguro, fuera del alcance de los niños. No tiree ni retuerza el cable al nivel del enchufe.

ADVERTENCIA: SI CREE QUE NO HAY CORRIENTE CUANDO EL APARATO ESTÁ APAGADO, ESTÁ EQUIVOCADO.

MANTÉNGALO ALEJADO DEL AGUA



Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe los aparatos eléctricos después del uso.

SIEMPRE DESENCHUFE LOS APARATOS PEQUEÑOS

CONSEJOS ESENCIALES DE USO

Para cuidar adecuadamente tu cabello y utilizar eficazmente tu plancha BaBylissPRO Nano TitaniumXL™, sigue estos consejos fundamentales:

Utilice el ajuste de temperatura adecuado según su tipo y condición de cabello. Consulte la tabla de temperaturas proporcionada y opte por la opción más adecuada. Para cabellos decolorados o muy dañados, es recomendable utilizar una temperatura más baja.

Aplica siempre un protector térmico en tu cabello antes de utilizar la plancha. Esta capa protectora ayuda a proteger el cabello del daño causado por el calor.

Evita exponer tu cabello a una exposición excesiva al calor. Abstenerse de mantener la plancha fija en cualquier sección del cabello durante períodos prolongados. La cantidad de pasadas necesarias en cada sección varía según factores como el tipo de cabello, el ajuste de la temperatura, los tratamientos continuos como aplicaciones de queratina y más. Asegúrate de deslizar la plancha sobre cada segmento de cabello solo según sea necesario. Consulte la tabla de temperaturas para obtener orientación.

Temperatura	Tipo de Cabello	Para Alisado	Para Keratina
		Configuración de Placas: Flotantes	Configuración de Placas: Fijas
		*Numero de Pasadas	*Numero de Pasadas
300°F/150°C	Frágil	3	10
330°F/165°C	Muy Fino	3	10
360°F/180°C	Docil	3-5	10-15
390°F/200°C	Normal	3-5	10-15
420°F/215°C	Rizado	3-5	10-15
450°F/230°C	Grueso	3-5	10-15
485°F/250°C	Muy Espeso	3-5	10-15

*Tenga en cuenta que, si bien estas pautas se basaron en pruebas realizadas por estilistas profesionales en un salón de belleza, los resultados individuales pueden variar según la condición del cabello, el grosor, la percepción del usuario y las preferencias de estilo deseadas.

You can download the manual on our website. Você pode baixar o manual em nosso site. Puede descargar el manual en nuestro sitio web. <https://www.babylissprola.com/manuales/>

SEGUIMOS EM: FOLLOW US: SÍGANOS EN:

- www.babylissprola.com
- @BaBylissPROLA
- @BaBylissPROLA
- @BaBylissPROLA

©2025 BaBylissPRO

Model BNT9000TXLUX

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

IB-25/419